


Griff TERNI  
Bouton TERNI  
Pomo TERNI

NEW




	Chrom chrome cromado	Nickel matt satiné satinado	Aluminium aluminium aluminio	Edelstahl optik acier brossé acero pulido	gebürstetes Altmessing laiton antique brossé latón envejecido pulido
Knopf bouton pomo	GZ-TERNI-1-01	GZ-TERNI-1-02	GZ-TERNI-1-05	GZ-TERNI-1-06	GZ-TERNI-1-09



	weiß blanc blanco	Schwarzchrom chrome noir negro cromado	Kupfer cuivre cobre	Gold Messing laiton doré latón dorado	schwarz matt noir mat negro mate	ZnAl
Knopf bouton pomo	GZ-TERNI-1-10	GZ-TERNI-1-12	GZ-TERNI-1-15	GZ-TERNI-1-16	GZ-TERNI-1-20M	

Griff GZ-1155  
Bouton GZ-1155  
Pomo GZ-1155



	Chrom chrome cromado	ZnAl
Knopf bouton pomo	GZ-WP1155-01	