











Knopf GZ-CRPA
Bouton GZ-CRPA
Tirador GZ-CRPA



 mm	 mm				
		Chrom, weißer Kristall chrome, blanc cristal cromado, cristal blanco	Chrom, schwarzer Kristall chrome, noir cristal cromado, cristal negro	Messing, weißer Kristall bronce, blanc cristal latón, cristal blanco	ZnAl, Glas ZnAl, verre ZnAl, vidrio
20	33	GZ-CRPA20-01	-	-	
25	37	GZ-CRPA25-01	-	-	
30	44	GZ-CRPA30-01	GZ-CRPA30-A1	GZ-CRPA30-03	
40	55	GZ-CRPA40-01	-	-	

Knopf GZ-CRPB
Bouton GZ-CRPB
Tirador GZ-CRPB



 mm	 mm				
		Chrom, weißer Kristall chrome, blanc cristal cromado, cristal blanco	Chrom, schwarzer Kristall chrome, noir cristal cromado, cristal negro	Messing, weißer Kristall bronce, blanc cristal latón, cristal blanco	ZnAl, Glas ZnAl, verre ZnAl, vidrio
20	26	GZ-CRPB20-01	-	-	
25	28	GZ-CRPB25-01	GZ-CRPB25-A1	-	
30	30	GZ-CRPB30-01	GZ-CRPB30-A1	GZ-CRPB30-03	
40	38	GZ-CRPB40-01	GZ-CRPB40-A1	-	